


# Hybrid Inverter

SUNT-6.0kW-S












## User Manual

6.0kW HYBRID INVERTER

# Table of Contents

<b>1. About This Manual</b> .....	<b>1</b>
<b>2. Safety Instructions</b> .....	<b>2</b>
2.1 PV Safety Guidelines .....	2
2.2 Inverter Safety Guidelines.....	2
2.3 Battery Safety Guidelines .....	3
<b>3. Parts List</b> .....	<b>3</b>
<b>4. Product Overview</b> .....	<b>4</b>
<b>5. Installation Location Guidelines</b> .....	<b>8</b>
<b>6. Mounting Instructions</b> .....	<b>12</b>
<b>7. Connection</b> .....	<b>13</b>
7.1 PV Connection.....	13
7.2 Battery Connection .....	16
7.3 Grid, Load and Generator Connection.....	19
7.4 Wire Current Transformer (CT) Connection .....	22
7.5 Parallel Connection .....	24
7.6 Ground Point Connection .....	31
7.7 Steps to Turn On/Off the Inverter .....	33
<b>8. System Overview</b> .....	<b>34</b>
<b>9. LCD Screen Overview</b> .....	<b>35</b>
9.1 LED Overview .....	35
9.2 Main Interface Overview .....	36
<b>10. Work Mode Overview</b> .....	<b>38</b>
10.1 Essential Load & Home Load.....	38
10.2 Work Mode Overview .....	39
<b>11. GEN Port Settings</b> .....	<b>47</b>
<b>12. Work Mode Settings</b> .....	<b>49</b>
12.1 Battery Settings Overview .....	49
12.2 UPS Mode .....	52
12.3 Zero Export Mode .....	55
12.4 Sell Mode .....	60
12.5 GEN Mode.....	63
<b>13. Troubleshooting</b> .....	<b>66</b>
<b>14. Technical Parameters</b> .....	<b>68</b>

	<p>Please ensure to review the enclosed documentation thoroughly.</p>
	<p>CE Mark: This inverter adheres to the requirements set forth by the relevant CE guidelines.</p>
	<p>Do not operate this inverter until it has been completely isolated from the battery, mains and any on-site photovoltaic generation sources.</p>
	<p>Additional Ground Point.</p>
	<p>It is imperative that the inverter is not disposed of alongside household waste.</p>
	<p>Caution: The surface of the inverter may become hot during operation; therefore, do not touch a running inverter.</p>
	<p>Warning: There exists a risk of electric shock; high voltage is present once the inverter is powered on.</p>
	<p>Notice: Potential hazards may arise after the inverter is activated.</p>
	<p>Warning: High voltage may be present; do not touch live components for a minimum of five minutes after disconnection from the power sources.</p>

# 1. About This Manual

This guide is an important resource for the **SUNT-6.0kW-S** inverter. It provides key information on how to install, set up, control, maintain and fix the inverter.

Before using the inverter, it's essential to read this guide carefully to ensure you understand how to operate it safely and effectively.

This manual is intended for the following inverter models:

## **SUNT-6.0kW-S**

- **SUNT:** Product Series.
- **6.0kW:** Nominal output capacity of 6.0kW.
- **S:** A premium IP65 variant, meticulously engineered to thrive within a diverse spectrum of complex environments.

Installation, maintenance and grid interfacing for this inverter should only be performed by qualified personnel who meet these criteria:

- Hold relevant certifications and comply with local and national regulations.
- Have a comprehensive understanding of this manual, as well as expertise in photovoltaic systems, battery technology and electrical engineering principles.

Change History

Version 1.1 (2025-10-17)

## 2. Safety Instructions

### 2.1 PV Safety Guidelines

- 1.The total open circuit voltage and input DC voltage (PV) must be lower than the maximum DC input voltage (Inverter); otherwise, overvoltage will cause irreversible damage to the inverter, and any damage caused by PV overvoltage is and will not be covered by warranty.
- 2.When installing PV systems, it is essential to include overvoltage protection by using surge arresters. The inverter is already equipped with SPDs on both the PV input and Grid sides. We recommend consulting a professional before installing SPDs.
- 3.Exposing photovoltaic (PV) modules to sunlight produces high direct current (DC) voltage, which poses a risk of electric shock and can lead to serious injuries or even death. Therefore, users should always avoid touching the positive or negative poles of the PV connecting device, and they must never touch both poles at the same time.
- 4.The wiring for the photovoltaic (PV) modules must be performed by individuals with relevant qualifications.

### 2.2 Inverter Safety Guidelines

- 1.Do not power on the inverter until all installation procedures have been fully completed.
- 2.It is essential to use a dedicated power supply line protected by a circuit breaker. Ensure that all wiring maintains a minimum clearance of 3mm for safety.
- 3.The inverter must be properly grounded, and the supply line should be equipped with an appropriate circuit breaker and a Residual Current Device (RCD) to protect the operator.  
**Notice: The internal grounding (PE) conductor size of this inverter is [5.2 mm<sup>2</sup>] (10 AWG ).**
- 4.This inverter is not designed for explosive environments. Do not install the inverter in locations that pose an explosion risk.

5. Users should never touch electrical components immediately after disconnecting the power supply. Wait at least 5 minutes before handling any components.










6. This unit does not contain user-serviceable parts. For maintenance or repairs, always consult a qualified technician.

## 2.3 Battery Safety Guidelines

1. Always follow the safety instructions provided in the battery manual when handling the battery. The battery used with the inverter must meet the specified requirements for the inverter series.

2. This inverter is designed to work with low-voltage batteries. For detailed information on battery type, nominal voltage and nominal capacity, please refer to the specification sheet in this manual. Make sure to consult the corresponding battery specifications for more details.

## 3. Parts List

 <p>1pc</p>	 <p>1pc</p>	 <p>2pcs</p>
 <p>1pc</p>	 <p>2pcs</p>	 <p>2pcs</p>
 <p>1pc</p>	 <p>1pc</p>	 <p>2pcs</p>

## 4. Product Overview

### ► LCD Touchscreen:

The inverter features a user-friendly touchscreen LCD that enables real-time monitoring of system status and easy configuration of all operational settings.


### ► Power ON/OFF Switch:

A DC-DC switch allows the battery to increase its voltage to the high-voltage bus needed to power the inverter's internal circuits, allowing for both inversion and charging functions.


### ► PV Switch:

Facilitates the connection or disconnection of the photovoltaic (PV) input.

LCD Touchscreen







## ► Electrical Connection Area:



This section includes various terminals for different connections:

- **PV1/PV2:** For connecting the photovoltaic module.
- **COM1/COM2:** Includes terminals for parallel function, BMS (Battery management System), Smart Meter/RS485 and Remote CT (wireless current transformer).
- **GEN:** For connecting the generator.
- **LOAD:** For connecting the **Essential load**.
- **GRID:** For connecting the electrical grid.
- **LIMITER/CT:** For connecting wired current transformer.
- **GEN-S:** For connecting dry contact signal to start the diesel generator.
- **WIFI/RS232:** This module supports wireless communication and monitoring. Its functionality could be expanded based on customer requirements, including customized software and hardware.
- **BAT+/BAT-:** For connecting the battery.
- **Ground Connection:** Ensure proper ground connection for safety and system stability.





## 5. Installation Location Guidelines

---

To ensure the proper functioning and longevity of the inverter, avoid installing it in the following areas:

**1.High Salt Content Areas:** Locations with a marine environment or high salt content can cause deterioration of metal components, leading to failure or water leakage in the unit.

**2.Oil or Steam-Rich Environments:** Avoid areas such as kitchens or areas where mineral oils or large amounts of splashed oil or steam may be present. These conditions can degrade plastic parts and lead to failure or water leakage.

**3.Corrosive Gas Environments:** Do not install the inverter in areas where sulfuric gas, chlorine gas, acids or alkalis are present. These substances can corrode copper pipes and brazed joints, potentially causing refrigerant leaks.

**4.Explosive or Flammable Environment:** Do not install the unit where combustible gases may leak, or in environments with suspended carbon fibers, flammable dust or volatile inflammables such as paint thinner or gasoline. These conditions may cause fire hazards.

**5.Gas Leak Risk Areas:** Avoid locations where gas leaks may occur or settle around the unit, as this could create a fire risk.


**6.Animal Exposure Areas:** Do not place the unit where animals may urinate on it or where ammonia could be generated, as this could damage the unit.

**7.High Altitudes:** Do not install the inverter at altitudes higher than **4000 meters (13123 Feet)** above sea level, as this may affect its performance.

**8.Low Air Circulation Areas:** Avoid installing the inverter in locations with poor ventilation, as adequate airflow is essential for proper heat dissipation.

**9.Direct Exposure to Sun, Rain or Snow:** The unit should not be exposed to direct sunlight, heavy rain or snow accumulation, as this can damage the system.

**10.Flammable or Explosive Materials:** Do not install the inverter near flammable, explosive, or corrosive materials, or near antennae.



► **Additional Installation Considerations:**

**1.Distance from TV/Radio Receivers:** Install the indoor unit, outdoor unit, power supply cable, transmission cable and remote control cable at least **1 meter (3.3 feet)** away from television or radio receivers. This prevents interference with TV reception and radio noise. Even with a distance of 1 meter, interference may still occur under certain signal conditions.

**2.Child Safety:** If children under 10 years old may be in proximity to the unit, take precautions to prevent them from coming into contact with it.

**3.Indoor Unit Height:** Install the indoor unit at a height of **160cm (5.3 feet)** from the floor for optimal performance and ease of access.

► **Environmental Conditions for Installation:**


**Ambient Temperature Range:** The inverter should be installed in an environment where the ambient temperature is between **-25°C to 60°C**.

**1.Humidity:** The relative humidity should be between **4-100% RH**.


**2.Ventilation:** It is important to install the inverter in a location that allows for sufficient ventilation to promote effective heat dissipation. If the inverter is mounted outdoors, it is recommended to install an awning or similar protection to shield it from harsh weather conditions.

**3.Suitable Mounting Surface:** Ensure the inverter is installed on a vertical, load-bearing wall, preferably made of concrete or another non-flammable material.

**4.Optimal Viewing:** Install the inverter at eye level for easy viewing of the LCD display.








**5. Clearances for Air Circulation:** To facilitate proper air circulation and prevent overheating, allow a clearance of **approximately 50cm (19.7 inches)** on each side, **50cm above** and **below** the unit, and **100cm in front**.




The guidelines in this chapter are crucial for ensuring that the inverter operates efficiently and safely.

# 6. Mounting Instructions

<p><b>1</b></p>  <p>Mark the drill positions using the metal plate on the back of the inverter. Measure carefully to ensure proper alignment.</p>	<p><b>2</b></p>  <p>Drill two holes, each 10mm (0.39 inch) wide and 51-56mm (2-2.2 inches) deep.</p>
<p><b>3</b></p>  <p>Use a hammer to insert the expansion bolts into the holes, ensuring they are securely seated.</p>	<p><b>4</b></p>  <p>Mount the bracket to the wall using the two expansion bolts. Tighten the bolts, then cover them with the included screw caps.</p>
<p><b>5</b></p>  <p>Hang the inverter onto the bracket's hook structure, making sure it is securely in place.</p>	

# 7. Connection



**Notice:**

In the following paragraph, the **Port** refers to all the interfaces at the bottom of the inverter, and the **Terminal** refers to the interface within the inverter.

## 7.1 PV Connection

### 7.1.1 PV Module Selection

1. Calculate **Open Circuit Voltage (Voc)**: Ensure the **total Voc** of each MPPT string is between **150V** and **500V**. Exceeding 500V may damage the inverter and should be strictly avoided.
2. Determine Power Requirements: The maximum DC input power is **9600W**.
3. Use PV modules of the same model within the same MPPT channel.
4. Ensure uniform quantity, alignment and tilt within each string.
5. Use positive cables of the PV modules to connect positive DC connectors, and negative cables of the PV modules to connect negative DC connectors.
6. Check PV Array Voltage: Use a multimeter to measure the voltage of the PV array. If abnormalities are detected, fix them before proceeding.

### 7.1.2 PV Cable Selection

We recommend the following wire specifications for a 6.0kW hybrid inverter:

- Wire Size: **10AWG**
- Maximum Current: **23.7A**
- Cable Cross-Section Size: **5.2mm<sup>2</sup>**

### 7.1.3 Steps to Assemble the MC4 Connector and PV Cable

**1.Strip the Cable:** Remove insulation from the PV cable to expose the appropriate length, ensure that the PV pin contact completely cover the exposed wire.

**2.Insert the Cable:** Place the stripped cable into the PV pin contact.


**3.Crimp:** Ensure proper alignment and use a PV crimping tool for secure crimping. Always use a crimping tool specifically designed for PV installations to guarantee secure and reliable connections.

**4.Assemble the Connector:** Thread the cable through the swivel nut, insert it into the connector, and listen for a "click" that indicates correct connection.

**5.Test the Connection:** Gently pull the cable to confirm a secure connection, then tighten the swivel nut.

**6.Voltage Check:** Use a **multimeter** to verify that total open circuit voltage does not exceed the input limit of **500V**. If the voltage reading is negative, it indicates incorrect DC input polarity. Please check if the multimeter wiring connections are correct, and make sure the PV connectors are properly connected.

### 7.1.4 Connect the Assembled PV Connectors to the Inverter



**1.Remove Caps:** Remove the PV port caps from the inverter.

**2.Verify Polarity:** Ensure the PV positive terminal connects to the inverter's positive port, and the negative terminal connects to the negative port before connecting.

**3.Insert Connector:** Connect the PV+ and PV- connector from the string to the corresponding inverter ports. Ensure an audible "click" to confirm proper connection.

### 7.1.5 Notice

Cover any unused PV ports with the original waterproof port caps. If all PV ports are in use, store the original waterproof port caps in a safe place.

When disconnecting connectors from the ports, quickly replace the original waterproof port caps to prevent moisture and dirt from entering.

## 7.2 Battery Connection

### 7.2.1 Battery Selection

1. Compatible with **LiFePO4** and **lead-acid** batteries.
2. Battery input voltage must be between **40V** and **60V**.
3. Prefer batteries with a Battery Management System (BMS) for enhanced safety.

### 7.2.2 Battery Cable Specifications

Recommended specifications for the battery cable:

- Wire Size: **2AWG**
- Maximum Current: **151.3A**
- Cable Cross-Section Size: **33.6mm<sup>2</sup>**


### 7.2.3 Precautions Before Connecting

- Ensure the **breaker, power button** (if applicable) and **DC switch** (if applicable) of the battery are all turned off.
- Verify **correct polarity** to avoid causing damage to the inverter.
- If a battery includes an **internal DC breaker**, no additional breaker is required unless mandated by local regulations.


### 7.2.4 Steps to Connect the Battery

- 1. Cable Selection:** Select an appropriate cable with connectors compatible with the battery terminals.
- 2. Plug Preparation:** Disassemble the BAT+ and BAT- ports. Then remove the plug and make a hole in each plug to allow the cable to pass through.
- 3. Insert Cable:** Insert the battery cable through the swivel nut, position it directly above the battery terminal.
- 4. Attach Cable:** Remove the screws from the battery terminal, attach the battery cable to the terminal, ensure the positive cable into BAT+ port and the negative cable to BAT- port, use a screwdriver to tighten the screws, then tighten the swivel nut.

**5. Check Polarity:** Confirm polarity alignment between the battery and inverter. Please ensure that the positive terminal of the battery is connected to the positive terminal of the inverter, and the negative terminal of the battery is connected to the negative terminal of the inverter.



## 7.2.5 BMS Communication



### Steps to Connect the BMS Communication Cable:

- 1. Disassemble COM1 or COM2:** Remove the plug, take out the two cylindrical inserts from inside the plug, and thread the communication cable through either **COM1** or **COM2**.
- 2. Insert the Cable:** Pass the cable through the swivel nut, then connect it to the BMS terminal.
- 3. Secure the Connection:** Tighten the swivel nut to finalize the installation.

Our inverters use the **CAN 500kbps** and **CAN 250kbps** protocols for communication with BMS- equipped batteries. The communication cable is included in the inverter package. For the exact protocol supported, please visit [http://www.lumentree.co/?list\\_42/](http://www.lumentree.co/?list_42/), or scan the QR code below.



## 7.3 Grid, Load and Generator Connection

### 7.3.1 Grid, Load Cable Selection


We recommend using the following specifications:

- Wire Size: **8AWG**
- Maximum Current: **37.7A**
- Cable Cross-Section Size: **8.3mm<sup>2</sup>**

### 7.3.2 Generator Cable Selection

Please select the appropriate cable based on the output current of the engine. For specific cables, please refer to the "American Wire Gauge (AWG) Chart" for more details.

### 7.3.3 Grid, Load and Generator Wiring



For proper operation, it is essential to correctly connect the live wire, neutral wire and ground wire to the corresponding ports on the inverter. The **GRID**, **LOAD** and **GEN** terminals are clearly marked with white lettering inside the inverter.

## **Wiring Procedure:**

### **1.Preparation:**

- Ensure that the inverter and all associated equipment are powered off and disconnected from the electrical supply before proceeding with any wiring.
- Strip the insulation from each wire to the appropriate length to fit the corresponding terminal.
- Disassemble the **GEN, LOAD** and **GRID** ports. Then remove the plug and create a hole in each plug to allow the cable to pass through.

### **2.Connecting Wires to the Inverter:**

- Using a suitable screwdriver, loosen the screw on each terminal (**GEN, LOAD, GRID**).
- Insert the stripped wires through the swivel nut into the corresponding terminal (**GEN, LOAD, GRID**). Ensure each wire is inserted correctly according to its polarity.
- Tighten the screws with a screwdriver.
- Reattach the plug and tighten the swivel nuts on each port (**GEN, LOAD, GRID**).

### **3.Double-Check Connections:**

Verify that the live wire, neutral wire and ground wire are securely connected to their designated ports. Incorrect connections may result in system malfunction, electrical hazards or equipment damage.

## **7.3.4 Additional Step for Generators with Dry Contact Signal to Startup**

GEN-S is used for the inverter to control the generator via the signal wire. Connect the dry contact signal wire as follows:

**1.Preparation:** Disassemble the GEN-S port, then remove the plug.

### **2.Disassemble GEN-S port and terminal:**

Unscrew the cap on the GEN-S port, then use a screwdriver to loosen the GEN-S terminal where the control wire from the diesel generator will be connected.


### 3.Insert the control wire:

Pass the control wire from the diesel generator through the swivel nut and cap, then connect it to the GEN-S terminal.

### 4.Tighten the terminal:

Use a screwdriver to securely tighten the GEN-S terminal, ensuring the wire is properly connected.

### 5.Screw the cap back and tighten the swivel nut



This step-by-step process ensures a secure and safe connection for the grid, load and generator. If any issues arise or if you are unsure about the connections, consult a qualified professional to ensure proper setup and prevent damage to the system.

### Notice:

#### 1.Install an AC Circuit Breaker

To ensure safety, users should place an AC circuit breaker (AC switch) between the inverter and the grid.

#### 2.Add a Load Disconnection Device

A load disconnection device should be installed for each inverter to allow safe disconnection while under load.

## 7.4 Wire Current Transformer (CT) Connection

The Current Transformer (CT) is a key component of the hybrid inverter system, used to monitor and manage electricity flow. Each inverter is supplied with one CT.

### 7.4.1 Important Installation Guidelines

**1.Arrow Direction:** Place the CT clamp on the **live wire (L)**, ensuring the arrow points toward the inverter.


**2.Avoid the following Mistakes:**

- Do not place the CT on the neutral (N) or ground (PE) wire.
- Do not place the CT on both neutral (N) and live (L) wires together.

**3.Use Insulated Wires Only:** The CT must not be installed on bare wires.

**4.Safety Tip:** Wrap the CT clip with insulating tape for extra protection.

The CT coil is essential for features like the "Zero Export" function, which prevents power from being sent to the grid by reducing the inverter's output power. Additionally, the CT is imperative for enabling the function of AC coupling, for receiving power from the existing string or microinverter.




### 7.4.2 Installation Steps

**1.Positioning the CT:** Place the CT clamp on the **live wire** coming from the main fuse that supplies power to the building.

**2.Cable Extension:** If needed, contact us for extended current transformers.

### 3.Connecting to the Inverter:

- Unscrew the cap on the LIMITER/CT port.
- Use a screwdriver to loosen the CT terminal.
- Insert the CT wire through the cap and the swivel nut, and into the CT terminal.
- Tighten the CT terminal securely with a screwdriver to ensure the wire is properly connected.
- Reattach the cap and tighten the swivel nut.




#### 7.4.3 Important Note

If the CT coil is installed incorrectly (with the arrow pointing in the wrong direction), the "Grid" icon on the LCD touchscreen's "Home Page" will display negative power readings. When installed correctly, it will show positive power readings. Incorrect installation will prevent the inverter from properly controlling the amount of power sent back to the grid. To correct this, remove the current transformer (CT) and reinstall it in the reverse direction.

## 7.5 Parallel Connection

**Notice:** It is recommended that the maximum number of inverters connected in parallel should not exceed 6 units.

The following diagram illustrates the process of connecting multiple inverters in parallel.




**First to Second Inverter:** Connect the first inverter to the second using communication cable, ensuring the cable is plugged into the correctly labeled terminal as shown in the diagram above.

**Second to Third Inverter:** Connect the second inverter to the third using communication cable, ensuring the cable is plugged into the correctly labeled interfaces as shown in the diagram above.


## SUNT Hybrid Inverter Multiple inverters working together:

Consist a **single-phase** system.



Battery packs need to be connected in parallel,  
positive polars connected together  
and negative polars conected together.

## Operating Guide:



↓ ↓

1. Configure this setting using the LCD touchscreen on the first inverter.



↓ ↓


2. Configure this setting using the LCD touchscreen on the second inverter.



3. Configure this setting using the LCD touchscreen on the third inverter.


## SUNT Hybrid Inverter Multiple inverters working together:

Consist a **three-phase** system.




Battery packs need to be connected in parallel,  
positive polars connected together  
and negative polars conencted together.


## Operating Guide:



1. Configure this setting using the LCD touchscreen on the first inverter.



2. Configure this setting using the LCD touchscreen on the second inverter.



3. Configure this setting using the LCD touchscreen on the third inverter.

#### Notice:

Follow the standard settings sequence during initial setup.

#### Installation Complete Indicators:

When the grid is connected, a blue light on the LCD interface under "AC/INV" indicates successful installation.

When the grid is not connected, a green light on the LCD interface under "AC/INV" signifies successful installation.


Occasionally, the phase configuration of the three-phase inverter system may change. If the system does not provide the correct feedback, please try the following adjustments:

**1. Set Second Inverter:** Configure the second inverter as **Master (L3)**.

**2. Set Third Inverter:** Configure the third inverter as **Master (L2)**.

If the power of a three-phase system consisting of three inverters in parallel is still insufficient, additional slave units can be connected to the master unit of each phase. The number of slave units connected to each phase must be the same. It is recommended that the total number of inverters in the system not exceed **six**.

## 7.6 Ground Point Connection



Follow these steps to ensure a proper ground connection:

- 1.Loosen the Screw:** Use a screwdriver to unscrew the screw in the connection area.
- 2.Attach the Wire:** Connect the wire securely to the ground point.
- 3.Secure the Connection:** Tighten the screw with the screwdriver to firmly fix the wire in place.


### **Safety Notice:**


- **Ensure Proper Grounding:** Always make sure the inverter is properly grounded to prevent electrical hazards. (This inverter is suitable for TN earthing systems; PE must be earthed; Internal N-PE bonding is strictly prohibited)
- **Power Off Before Connecting:** Always ensure the system is powered off before performing any electrical connections to prevent the risk of electric shock.


**Important:** Following these safety guidelines helps protect you and ensures the reliable operation of your system.

## 7.7 Steps to Turn On/Off the Inverter

### Turn On


- 


Press the "ON/OFF" button to boost the battery voltage and enable inverting.
- 


Activate the grid power by turning on the circuit breaker on the power supply side of the grid.
- 

Turn on the PV switch to allow energy from the solar panels to flow into the system.

### Turn Off


- 

Disengage the battery for inversion by pressing the "ON/OFF" button.
- 

Turn off the PV switch to disconnect the solar panels from the inverter.
- 

Disconnect grid power by turning off the circuit breaker on the power supply side of the grid.

## 8. System Overview



The **SUNT-6.0kW-S** inverter is a cutting-edge energy storage solution, specifically designed to optimize the grid integration of **photovoltaic (PV)** systems.

### ► Photovoltaic Modules:

The inverter operates in **Maximum Power Point Tracking (MPPT)** method and is equipped with **dual MPPTs**, enhancing system efficiency by ensuring optimal power generation under various environmental conditions.

### ► Battery System:

The **SUNT-6.0kW-S** inverter is compatible with **low-voltage batteries** (both **lithium** and **lead-Acid**), the SUNT-6.0kW-S series allows the installation of batteries with identical capacities and models. The inverter communicates with the battery via a **Battery Management System (BMS)**, ensuring compliance with industry standards and regulatory requirements.

### ► Current Transformer (CT):

The integrated **CT** enables the inverter to track energy import/export and consumption, facilitating efficient battery charge and discharge management for optimized energy use.

► **Generator Integration:**

The **Gen Mode** effectively integrates **photovoltaic systems with diesel generators**, maximizing fuel savings, reducing energy costs and ensuring a stable and reliable power supply.

► **Grid Compatibility:**

The inverter is compatible with grid voltages of 220V, 230V and 240V, making it suitable for various electrical systems. The parameters can be adjusted based on the installation country to better accommodate the local grid requirements.


► **LightEarth:**

The **LightEarth** serves as a smart, versatile monitoring tool that offers remote access. Through the LightEarth platform, both operators and installers can access vital information and stay updated on system performance, while also allowing them to control and adjust parameters to regulate the energy flow remotely, either via Bluetooth or Wi-Fi. Users can download the app using the QR code below.



## 9. LCD Screen Overview

### 9.1 LED Overview



Type	Color Indicator	Description
AC/INV	● BLUE	The inverter is active and connected to the grid.
	● GREEN	The inverter is active in off-grid mode.
CHARGE	● YELLOW	Battery is charging.
	● OFF	Battery is not charging.
FAULT	● RED	A fault has occurred. The light stays on until the fault is cleared or the system is restarted.
	● OFF	System is functioning normally.
WIFI/BLE	● GREEN	The inverter is connected to Bluetooth.
	● BLUE	The inverter is connected to Wi-Fi.
	● OFF	There is inactive connection.

## 9.2 Main Interface Overview



Home Page	
Top Row	<ul style="list-style-type: none"> <li>• Display SN (for app networking).</li> <li>• Display the Wi-Fi or Bluetooth icon.</li> <li>• Display the parallel status.</li> <li>• Display the date and time.</li> </ul>
Middle Section	<ul style="list-style-type: none"> <li>• Left: Display the connection status and power flow of the inverter and devices.</li> <li>• Right: Display voltage, current and power data. Tap device icons for details.</li> </ul>
Bottom Row	Select the <b>Home</b> , <b>Statistics</b> and <b>Settings</b> options to switch between the main interface, statistics page and settings page.
Statistics Page	
Statistics	View daily and total power data for PV, Grid (CT), Essential Load, Home Load and Battery.

Home Page	
Top Row	<ul style="list-style-type: none"> <li>• <b>Set Date:</b> Set the display date of the inverter.</li> <li>• <b>Set Time:</b> Set the display time of the inverter.</li> <li>• <b>Language:</b> Select the language of the inverter system.</li> <li>• <b>Backlight Time:</b> Select the LCD screen on-time duration, options include <b>30 seconds</b>, <b>60 seconds</b> and <b>Always On</b>.</li> <li>• <b>Beep:</b> Select the the time duration of the inverter alarm sound, options include <b>Disable</b>, <b>30 seconds</b> and <b>Always On</b>.</li> <li>• <b>Backlight:</b> Slide the bar to adjust LCD touchscreen brightness.</li> </ul>
Middle Section	<ul style="list-style-type: none"> <li>• Choose <b>Standalone</b> (default) or other modes like <b>Single-Phase</b> and <b>Three-Phase</b>.</li> <li>• Configure Master-Slave roles for parallel function.</li> </ul>
Work Modes	Select modes Zero Export, UPS, Sell or GEN.
	<b>CT Connection Mode</b> (available under " <b>Zero Export</b> " mode): <ul style="list-style-type: none"> <li>• <b>Wire CT:</b> The standard current transformer used for <b>Zero Export</b> functionality.</li> <li>• <b>WiFi CT:</b> A wireless current transformer that connects via Wi-Fi.</li> <li>• <b>Bluetooth CT:</b> A wireless current transformer that operates over a local area network via Bluetooth.</li> </ul>
Battery Settings	For more details, refer to the " <b>Battery Settings</b> " under Chapter " <b>Work Mode Settings</b> ".
Work Control Settings	<ul style="list-style-type: none"> <li>• <b>Start Time:</b> Set the time for the battery to start charging/discharging.</li> <li>• <b>Stop Time:</b> Set the time for the battery to stop charging/discharging.</li> <li>• <b>Power:</b> Set the battery's maximum discharge power.</li> <li>• <b>Target:</b> Set the desired remaining battery capacity (SOC/Voltage).</li> <li>• <b>AC Charges Battery:</b> Select whether to charge the battery by toggling the switch in the right column of the interface.</li> <li>• <b>Battery Discharge:</b> Select whether to discharge the battery by toggling the switch in the right column of the interface.</li> <li>• <b>Max. Sell Power:</b> Set the maximum power that the inverter can sell electricity to the grid.</li> <li>• <b>Max. Discharge Current:</b> Set the maximum discharge current value of the battery when the inverter is grid-connected.</li> </ul>
Advanced Settings	<ul style="list-style-type: none"> <li>• <b>AC Output Frequency:</b> Select <b>50Hz</b> or <b>60Hz</b> based on local grid requirements.</li> <li>• <b>AC Output Voltage:</b> Select <b>220V</b>, <b>230V</b> or <b>240V</b> based on local grid requirements.</li> <li>• <b>CT Trickle Feed:</b> Set the power fed into the inverter from the grid, prevent backfeeding. (Available under "<b>Zero Export</b>" mode)</li> <li>• <b>AC Coupling:</b> Enable/disable for connecting microinverters.</li> <li>• <b>Solar Sell:</b> Sell excess PV power to the grid if permitted.</li> <li>• <b>Grid Peak Shaving:</b> Enable or disable the inverter's ability to draw power from the grid for system use.</li> <li>• <b>Grid Peak Shaving Power:</b> Specify the maximum amount of power that the inverter can draw from the grid when Grid Peak Shaving is enabled.</li> </ul>
The Device	<b>View details about the inverter software system.</b>
	Error Log: View <b>Fault code</b> , <b>Fault time</b> , <b>Fault description</b> .

# 10. Work Mode Overview

---

## 10.1 Essential Load & Home Load

In our system, loads are classified into two categories: **Essential Load** and **Home Load**.

Below is a detailed explanation of each category and connection methods.

### ► Essential Load:

Electrical appliances connected to the system's "**LOAD**" terminal are classified as **Essential Load**. These appliances require power even in the event of a grid outage, ensuring uninterrupted operation.

### ► Home Load:

All other electrical appliances in the household that are wired to the grid are considered **Home Load**. These devices are powered through the grid connection under normal operating conditions.

This design ensures critical devices receive prioritized power during power outages, while non-essential devices remain dependent on grid availability.

### ► Recommendation:

1. We suggest connecting loads to **Essential Load** that are critical systems that must remain operational at all times.

**Examples** include medical equipment and storage units, CCTV cameras, internet servers, Wi-Fi routers, refrigerators, desktop computers, etc.

2. We suggest connecting loads to **Home Load** that can tolerate power interruptions. These systems do not require constant electricity and can be powered on or off as needed.


**Examples** include non-critical household appliances: televisions, washing machines, dishwashers, electric kettles, microwave ovens, coffee makers, air conditioners, etc.

## 10.2 Work Mode Overview

### 10.2.1 UPS Mode

The UPS (Uninterruptible Power Supply) mode is a critical feature designed to ensure continuous power supply during grid outages. When enabling UPS mode and the grid fails, it draws power from the solar system or battery storage to maintain electricity for the household. This feature helps prevent downtime and ensures that essential devices continue to operate seamlessly.

UPS mode is particularly valuable in regions with unreliable grid service, providing peace of mind that power will remain available during disruptions. In this mode, the system functions as a backup power source, delivering energy instantly with no noticeable delay.



#### ► Key Features

**1.Normal Grid State:** The load is powered by solar energy and grid power. The battery is only charged and does not discharge.

**2.Grid Outage:** The system switches to off-grid mode, ensuring uninterrupted power supply to **Essential Load**.

## ► Operational Priorities

### 1. When the Grid is Available:

- **Battery at 100% State of Charge (SOC):** Solar power supplies the load as a priority. If solar power is insufficient, grid power supplements the load.
- **Battery Below 100% SOC:** Grid power supplies the load, while solar power charges the battery. If solar power is not available, the grid charges the battery.
- **Battery Discharge Policy:** The battery will not discharge to power the load when the grid is operational.
- **Solar Power Usage Priority:** Battery > Load > Grid

### 2. When the Grid is Unavailable:

- **Load Supply:** The load is powered by a combination of battery and solar power.
- **Excess Solar Power:** When the PV power exceeds the load power, the surplus energy will be used to charge the battery.

## ► Notice

1. Only the loads connected to the "**LOAD**" terminal, classified as **Essential Load**, will be functional in **UPS mode**.


2. In order to charge the battery using grid power, the "**Charge From AC**" option in "**Battery Settings**" must be enabled.

## 10.2.2 Zero Export Mode

Zero export mode is designed to prevent any surplus solar energy from being exported to the grid. When enabled, this mode prioritizes solar energy for powering loads, with any surplus energy stored in the battery for later use, with none being sent back to the grid.

This feature is particularly beneficial in regions with strict regulations or policies that restrict the export of solar energy. It gives users full control over their energy consumption and storage, ensuring that no energy is wasted and helping to minimize electricity costs. The system continuously monitors energy demand, adjusting the energy flow to maintain zero export levels.

Zero export mode can be programmed to activate automatically during certain hours or conditions, offering a convenient and hands-off approach. Additionally, it enhances grid stability by reducing the strain on local infrastructure caused by unpredictable energy exports.



### ► Key Features

- 1.This mode is ideal for maximizing solar energy utilization while complying with regulations that prohibit feed-in to the grid.
- 2.The Current Transformer (CT) is essential to realize the function of **Zero-Export**.
- 3.Battery Charging: If PV power exceeds load demands, the excess energy is used to charge the battery.
- 4.Make sure the "**Charge from AC**" under "**Battery Settings**" and "**AC Charges Battery**" under "**Work Control Settings**" are turned on to allow the battery to charge from the grid. If these settings are off, the battery will only be charged from excess photovoltaic (PV) power.

## ► Operational Priorities

### 1. Load Supply Priority: Solar > Battery > Grid

Solar energy is the primary power source for loads.

If solar power is insufficient, the battery will also supply power to loads, with the grid being the last option to satisfy the demand of load consumption.

### 2. Solar Power Consumption Priority: Load > Battery > Grid

Solar power is first used to meet load requirements.

Any excess solar power charges the battery.

### 3. The priority order of grid power distribution: Load > Battery

## 10.2.3 Solar Sell & AC Coupling

### ► Solar Sell

We have introduced the "**Solar Sell**" function under "**Advanced Settings**", enabling users to sell surplus solar energy back to the grid where permitted by local authorities. This feature enhances flexibility and maximizes the value of solar power generation for users.

#### **How it Works:**

When the **Solar Sell** function is activated, any excess solar power that remains after fulfilling both loads and battery requirements can be exported to the grid for sale, providing users with an opportunity to monetize their excess energy production.

#### **Notice:**

- Ensure compliance with local regulations and permissions before activating the **Solar Sell** function.
- The **Solar Sell** function will be available when users select **Zero Export** mode or **UPS** mode.

### ► AC Coupling

To enhance energy efficiency, we have introduced the **AC Coupling** feature under "Advanced Settings" allowing users to integrate existing or additional microinverters and optimize solar energy harvesting.

Under Zero Export, the power generated by the microinverter is used to supply the **Essential Load** and **Home Load**. Any excess power is then used to charge the battery (with the "Charge From AC" option enabled in "Battery Settings"), and vice versa under UPS mode.

#### **How it Works:**

When the **AC Coupling** feature is set to **Enable** within the "**Advanced Settings**" section, connecting additional microinverters will allow for the export of the total energy generated by the combined inverters.

#### **Notice:**


The **AC Coupling** function will be available when users select **Zero Export** mode or **UPS** mode.

### **10.2.4 Sell Mode**

Sell mode is designed to optimize both energy production and consumption. When this feature is enabled, the inverter prioritizes charging the battery and powering the connected loads, with any surplus energy automatically fed back into the grid, provided such actions are permitted by local regulations. The inverter actively monitors the energy produced and consumed, and when there is surplus power, it automatically transfers to the grid. This helps balance the overall energy supply, supporting the grid during peak demand periods.

The inverter adjusts the export amount based on predefined settings, allowing users to control how much energy is sent back to the grid. This feature is particularly beneficial in regions with net metering programs, where users can receive compensation or credits for the energy they contribute to the grid. The system ensures that the energy exported is safe, reliable, and compliant with local grid standards.

Before enabling this feature, verify with your local utility or authority to confirm that selling electricity back to the grid is permitted. Additionally, ensure full compliance with all relevant regulations, guidelines, and permitting processes to avoid any issues.



## ► Key Features

**1. Battery Charging:** In **Sell Mode**, charging follows the two predefined time slots specified in **Work Control Settings**.

While in **UPS Mode**, the battery charges continuously until it reaches 100%.

**2. Grid Feedback:** In **Sell Mode**, feedback to the grid is automatically enabled, while in **UPS** and **Zero Export Modes**, feedback to the grid requires manual activation via **Advanced Settings** → **Solar Sell**.

### **3. Solar Sell vs. Sell Mode:**

**Sell Mode:** Users can sell electricity from both the battery and excess solar power.

**Solar Sell:** Users can only sell excess solar energy; the battery's power isn't used for sales.

## ► Operational Priorities

**1. Operational Priorities: Battery > Load > Grid**

## 2.Max Sell Power: The Max Sell Power setting controls the maximum amount of electricity that can be exported to the grid.


When "Sell Mode" is enabled, or when "Solar Sell" is activated under either "UPS Mode" or "Zero Export Mode", the excess solar power available for sale will be restricted based on the value set by the users in the "Max Sell Limit" field under "Work Control Settings".

### 10.2.5 GEN Mode

The generator mode enables the inverter to interface with an external generator, ensuring reliable power supply. In this mode, the inverter can utilize energy produced by both the solar system and the generator, helping it maintain optimal performance and efficiency.

When solar generation or battery storage is insufficient, the generator can be activated to provide the necessary backup power, ensuring an uninterrupted energy supply. This mode helps balance energy demand by supplementing the solar system with additional power when demand exceeds available energy.

Generator mode is particularly beneficial in off-grid applications or locations where grid access is unreliable or unavailable. It also helps reduce the operational cost of running a generator by utilizing free solar energy. By drawing on solar power when available, this mode minimizes fuel consumption and reduces the need for external fuel sources.



## ► Key Features

1. In GEN mode, the system automatically detects grid status. The generator is only allowed to operate when the grid is disconnected—either due to an outage or manual disconnection. If the grid is active, the system will block generator output, even if the generator is running.
2. To use the generator during non-outage periods (e.g., high tariff times), users must manually disconnect the grid to enable generator charging or load support.
3. Generator Load Capacity Management: Confirm that the total power output of the generator exceeds the sum of load power and battery charging power (calculated as Maximum Charge Current × Battery Voltage + Load). Failing to do so may trigger an overload error.
4. When the system is powered by the grid, the "Work Control Settings" can be configured. However, when the generator is supplying power to the system, the "Work Control Settings" become ineffective.
5. Gen Port Settings: Please refer to Chapter 12, for a complete tutorial guide on how to set up the specific parameters of the generator to intergrade with our current system.

## ► Operational Priorities

### **1. Load Supply Priority: Solar > Generator/Grid**

Solar power supplies the load first. If solar power is insufficient, either the generator or the grid takes over.

### **2. Solar Power Usage Priority: Load > Battery**


Excess solar energy not required by the load charges the battery.

### **3. Generator Power Distribution Priority: Load > Battery**

# 11. GEN Port Settings

For all of our S series hybrid inverters, we have introduced a new feature that allows the users to control the additional generator or string/microinverter under the page "GEN Port Settings".

► **Generator:**




1. GEN Charge: This toggle defines whether the generator is used to charge the battery.
2. GEN Peak Shaving: Controls whether GEN Peak Shaving Power is enabled or disabled. This setting here determines the inverter whether draw energy from the connected generator.
3. Gen Charges Current: This controls the charging current from the generator to the battery.
4. Gen Start Point: Sets the battery voltage threshold at which the generator will start charging the battery. e.g. Setting this to 40V(20%) means the generator will activate when the battery reaches below 40V(20%).
5. GEN Peak Shaving Power: The setting defines the maximum amount of power the inverter can draw from the generator.

6. Max. Operating Time: The setting limits the maximum runtime of the generator. This is important as most generators have a maximum runtime limit. The user should configure this setting based on their specific generator.

7. Max. Cooling Time: This setting specifies the cooling period required for the generator after extended operation, ensuring it operates within safe thermal limits. The user should configure this setting based on their specific generator.

► **Microinverter:**



Microinverter Limit:

1. When this option is enabled, the microinverter begins supplying power to the battery and loads connected to the hybrid inverter. Once the inverter and the current work mode requirements are met, any excess solar energy will be exported to the grid.

2. INV ON Batt Point: This setting defines the voltage at which the microinverter will start operating. e.g. Setting this to 40V(20%) will cause the inverter to turn on when the battery voltage reaches below 40V(20%).

**Notice:**

If the battery is equipped with a **Battery Management System (BMS)**, both "**Gen Start Point**" and "**INV ON Batt Point**" can be configured using either **Voltage** or **State of Charge (SOC)**.

Users can select the preferred mode under **Battery Settings** by choosing the "**SOC/Voltage**" option.

# 12. Work Mode Settings

## 12.1 Battery Settings Overview

Properly configuring the battery parameters is critical for safe and optimal system performance.

### ► Important Notices:

**1. Consult Your Battery Supplier:** Properly configuring the battery parameters is critical for safe and optimal system performance.

**2. Safety First:** Incorrect battery configurations can lead to damage, safety hazards, or even explosions. Always follow your battery manufacturer's guidelines and consult your battery supplier before adjusting any of the following settings.

### ► Battery Settings Configuration:

**1. Charge From AC:** This setting allows users to enable grid power for battery charging.

**2. Battery Type:** Select one of the following options based on your battery setup.

- **Battery Pack:** For batteries with a **BMS**.

Under **SOC/Voltage**, select either **SOC** or **Voltage** to configure the battery settings.

Choose the matching **Battery Protocol** for your battery.

To view the complete battery status, click the **BMS** option.

- **User:**

For batteries **without** a Battery Management System (**BMS**). Manually enter all relevant specifications after consulting with the battery supplier.

- **No Battery:**

If no battery is installed and the inverter is used solely as a grid-tie inverter, select this option.

**Notice:** The "**Boost Charge Voltage**" and "**Float Charge Voltage**" are automatically configured by the battery with Management System (**BMS**). If your battery does not include a **BMS**, you must manually set these voltages under the "**User**" option in the "**Battery Type**" settings.

**3. Battery Capacity:** This setting allows users to select the battery's total capacity.

**4. Low Voltage Protection:** This setting determines the voltage level at which the battery will stop discharging.

**5. Battery Recovery Voltage:** This setting represents the level of voltage that the battery needs to be charged up to after the low-voltage protection kicks in.

**6. Maximum Charge Current:** This setting allows users to set the maximum charge current.

**7. Maximum Discharge Current:** This setting allows users to set the maximum discharge current.

**8. Boost Charge Voltage:** This setting allows users to set the voltage reached during bulk (constant-current) charging.

**9. Float Charge Voltage:** A low, constant voltage is applied after the battery is fully charged to counter self-discharge. This is often unnecessary for LiFePO<sub>4</sub> batteries but commonly used for lead-acid batteries.

**10. Equalizing Charge Voltage:** Equalizing charge is primarily used for lead-acid batteries to balance the cells. It is typically required for lead-acid batteries, but not for LiFePO<sub>4</sub> batteries.

**11. Equalizing Charge Time:** If imbalance occurs (e.g., reduced performance or capacity), set the duration (1–90 minutes) for the equalizing charge. This is not required for LiFePO<sub>4</sub> batteries.

**12. Equalizing Charge Interval:** For lead-acid batteries, users should select the frequency (1–90 days) for an equalizing charge, depending on usage and battery condition. This is typically used for lead-acid batteries and is not required for LiFePO<sub>4</sub> batteries.

**ATTENTION:** Please note that the chart below uses theoretical data to illustrate how battery SOC and voltage may correlate. Actual performance varies by manufacturers and battery chemistry - particularly for LiFePO4 batteries - so the chart should be viewed as **reference only**.

The following hypothetical examples are based on the chart's data and assume sufficient solar irradiance. Real-World conditions will may vary.

SOC	Volt per Cell	48V (15 Cell)	51.2V (16 Cell)	57.6V (18 Cell)
100.00%	3.65	54.75	58.4	65.7
99.50%	3.45	51.75	55.2	62.1
99.00%	3.38	50.7	54.08	60.84
90.00%	3.35	50.25	53.6	60.3
80.00%	3.33	49.95	53.28	59.94
70.00%	3.3	49.5	52.8	59.4
60.00%	3.28	49.2	52.48	59.04
50.00%	3.26	48.9	52.16	58.68
40.00%	3.25	48.75	52	58.5
30%	3.23	48.45	51.68	58.14
20%	3.2	48	51.2	57.6
15%	3.05	45.75	48.8	54.9
9.5%	3	45	48	54
5%	2.8	42	44.8	50.4
0.5%	2.54	38.1	40.64	45.72
0%	2.5	37.5	40	45

The following hypothetical examples and operating guides are based on hypothetical assumptions. Actual performance will vary depending on local weather conditions, system efficiency and real energy consumption patterns.

## 12.2 UPS Mode



Brian lives in a country with an unstable electricity grid, resulting in frequent power outages. He seeks a reliable and continuous source of electricity to mitigate the impacts of these outages.

**Brian's Solar Equipment and Battery Specifications**

Category	Specs Description	Details
Solar Panels	Number of Panels	10x580W
	Type	LiFePO4 Battery
Battery	Battery Nominal Voltage	48V
	Battery Capacity	300Ah
	Battery Rated Discharge Current	130A
	Battery Rated Charge Current	120A

**Brian's Household Energy Usage**

Category	Appliance	Power (W/h)	Operating Hours	Daily Consumption (Wh)
Essential Load	1 Refrigerator	50	24	1200
	1 Medical Storage Equipment	100	24	2400
Home Load	5 Light Bulbs	10	5 (18:00-23:00)	250
	1 Television	100	3	300
	1 Induction Cooker	1500	1 (18:00-19:00)	1500
Total Daily Load				5650

### ► Solar Power Generation and Battery Charging:

With the solar panels Brian has, assuming an effective charging power of **80%** of the rated output due to real-world conditions, and inverter efficiency of **97.6%**.

**Total Solar Power:  $580\text{W} \times 10 \times 80\% \times 97.6\% \approx 4529\text{W} \approx 4.53\text{kW}$ .**

**Total Battery Energy:  $300\text{Ah} \times 48\text{V} = 14,400\text{Wh} = 14.4\text{kWh}$ .**

**Charging Time = Battery Energy (kWh) / Solar Power (kW)**  
 **$= 14.4\text{kWh} \div 4.53\text{kW} \approx 3.2\text{hours}$ .**

This means that with adequate sunlight, the solar system can fully recharge the battery in just over **3** hours with no load consumption.

### Self-Sufficiency and Backup Power

Given that Brian's battery has a total energy capacity of **14.4kWh**, which is more than sufficient to meet his daily consumption of **5650Wh (5.65kWh)**, he can depend entirely on the battery for his household's energy needs during the day if solar energy generation is sufficient.


In the event of extended grid outages (lasting up to two days with overcast skies and minimal solar energy generation), Brian will remain fully self-sufficient with his current setup, as long as his solar panels generate enough power during the day to recharge the battery.

To ensure a consistent supply of electricity in the household while reducing costs associated with electricity consumption, the following settings and strategies should be implemented.

## Operating Guide:



1. Navigate to "Work Modes" and select "UPS".



2. In UPS mode, Brian only needs to manage the battery settings. Here are our recommendations based on his situation.

## 12.3 Zero Export Mode



Phil lives in an area with exceptionally high electricity costs. Hypothetically, the electricity price is highest between 13:00–19:00 and lowest from 01:00–07:00. To minimize costs, he aims to maximize solar energy usage and avoid exporting excess power to the grid during expensive peak hours.

**Phil's Solar Equipment and Battery Specifications**

Category	Specs Description	Details
Solar Panels	Number of Panels	12×550W
	Type	LiFePO4 Battery
Battery	Battery Nominal Voltage	48V
	Battery Capacity	200Ah
	Battery Rated Discharge Current	100A
	Battery Rated Charge Current	100A


**Phil's Household Energy Usage**

Category	Appliance	Power (W/h)	Operating Hours	Daily Consumption (Wh)
Essential Load	1 Refrigerator	50	24	1200
	1 Internet Server	100	24	2400
Home Load	8 Light Bulbs	10	5 (18:00–23:00)	400
	1 Computer	100	10 (07:00–12:00 13:00–18:00)	1000
	1 Air Conditioner	1000	5 (18:00–23:00)	5000
Total Daily Load				10000


### ► Zero Export Mode Configuration:

- **Solar Energy Priority:** Configure the system to use solar energy as the primary source of power during the day.
- **Battery Charging:** Charge the battery using grid power during off-peak hours (01:00-07:00).
- **Battery Usage:** Use stored battery energy to power the home loads during peak hours (13:00-19:00).
- **Goal:** Minimize reliance on expensive grid electricity and avoid unnecessary energy export costs.


### Operating Guide:



1. Navigate to "Work Modes" and select "Zero Export"; the default CT connection is "Wire CT".



2. Based on Phil's case, we recommend these battery settings.



3. These are the most cost-effective grid settings for Phil to reduce electricity costs.

► **Solar Sell Function:**

If Phil's grid supports selling electricity but does not allow more than 3600W, for him to sell electricity, Phil will turn on the **"Solar Sell"** feature under **"Advanced Settings"** and set the **"Max Sell Power"** at 3600W.

Assuming 5 peak sunlight hours for this calculation, the total energy that could be sold to the grid is: **3600W×5h=18,000Wh=18kWh**.

The local energy company pays **\$0.07** per **kilowatt-hour (kWh)** for solar energy sold to the grid. This is Phil's daily earning with the "Solar Sell" feature enabled: **18kWh×\$0.07/kWh=\$1.26**.

**Operating Guide:**



1. Navigate to "Advanced Settings" and enable the "Solar Sell" feature.


SN : P241111111		2025-04-30 15:00:47	
	Start Time	Stop Time	Power Target
Basic Settings	AC Charges	Battery	
Parallel Modes	01 : 00	03 : 30	-- W 50.5 V <input checked="" type="checkbox"/>
Work Modes	00 : 00	00 : 00	-- W 0.0 V <input type="checkbox"/>
Battery Settings	Battery Discharge	03 : 31	23 : 59 4800 W 48.0 V <input checked="" type="checkbox"/>
Work Control Settings	00 : 00	00 : 00	1000 W 55.0 V <input type="checkbox"/>
Advanced Settings	00 : 00	00 : 00	1000 W 0.0 V <input type="checkbox"/>
The Device	MAX. Sell Power		3600 W
GEN Port Settings	MAX. Discharge Current		100 A
Home	Statistics	Settings	

2.If the solar energy selling price is higher than the grid electricity price in Phil's location, we recommend these settings.

SN : P241111111		2025-04-30 15:02:16	
	Start Time	Stop Time	Power Target
Basic Settings	AC Charges	Battery	
Parallel Modes	01 : 00	03 : 30	-- W 50.5 V <input type="checkbox"/>
Work Modes	00 : 00	00 : 00	-- W 0.0 V <input type="checkbox"/>
Battery Settings	Battery Discharge	13 : 00	23 : 59 4800 W 48.0 V <input checked="" type="checkbox"/>
Work Control Settings	00 : 00	00 : 00	1000 W 55.0 V <input type="checkbox"/>
Advanced Settings	00 : 00	00 : 00	1000 W 0.0 V <input type="checkbox"/>
The Device	MAX. Sell Power		3600 W
GEN Port Settings	MAX. Discharge Current		100 A
Home	Statistics	Settings	

3.If the solar energy selling price is lower than the grid electricity price in Phil's location, we recommend these settings.

## 12.4 Sell Mode



Alex lives in an area where the local grid allows individuals to sell electricity back to the grid, he has abundant solar panels on his roof with relatively small battery storage to store the solar energy, and he is interested in using our inverter to earn some extra income.

**Alex's Solar Equipment and Battery Specifications**

Category	Specs Description	Details
Solar Panels	Number of Panels	12×560W
	Type	LiFePO4 Battery
Battery	Battery Nominal Voltage	51.2V
	Battery Capacity	100Ah
	Battery Rated Discharge Current	100A
	Battery Rated Charge Current	100A

**Alex's Household Energy Usage**

Category	Appliance	Power (W/h)	Operating Hours	Daily Consumption (Wh)
Essential Load	1 Refrigerator	50	24	1200
	1 Wi-Fi Router	15	24	360
Home Load	3 Light Bulbs	10	5 (18:00-23:00)	150
	1 Television	100	3	300
	1 Toaster	800	0.25	200
Total Daily Load				2210

► **Hypothetical Scenario:**

With **12** units of **560W** solar panels, assuming an effective charging power of 80% of the rated output due to real-world conditions, and the inverter's efficiency of **97.6%**, the effective output power:

$$560W \times 12 \times 80\% \times 97.6\% = 5247W.$$

Assuming it's a sunny day with 6 hours of effective sunlight, the total energy generated by the solar panels would be:

$$5247W \times 6 = 31,482Wh.$$

After subtracting Alex's daily consumption of 1910Wh, the remaining energy available for export to the grid is:

$$31,482Wh - 2210Wh = 29,272Wh = 29.272kWh.$$

Potential Earnings: If the local grid purchases solar energy at \$0.05 per kWh, on this day, under this scenario, Alex could earn:


$$29.272kWh \times \$0.05/kWh \approx \$1.46.$$

**Operating Guide:**



↓ ↓

1. Navigate to "Work Modes" and select "Sell".



2. Configure the battery settings according to Alex's scenario.



3. This is our recommendation based on Alex's scenario. This setting can help him maximize his profit from selling electricity to the grid.

## 12.5 GEN Mode



Jason has relocated to a site where there is no connection to the electrical grid, and his only reliable power source is one 6.5kW diesel generator. His goal is to minimize diesel consumption while maximizing the use of solar energy to power his home.

### Jason's Solar Equipment and Battery Specifications

Category	Specs Description	Details
Solar Panels	Number of Panels	12×550W
	Type	LiFePO4 Battery
Battery	Battery Nominal Voltage	51.2V
	Battery Capacity	300Ah
	Battery Rated Discharge Current	130A
	Battery Rated Charge Current	120A

### Jason's Household Energy Usage

Category	Appliance	Power (W/h)	Operating Hours	Daily Consumption (Wh)
Essential Load	1 Refrigerator	50	24	1200
	1 Electric Tankless Water Heater	7	24	168
Home Load	2 Light Bulbs	10	5 (18:00-23:00)	100
	1 Television	100	3	300
	1 Induction Cooker	1500	1 (18:00-19:00)	1500
	1 Washing Machine	1500	1 (21:00-22:00)	1500
Total Daily Load				4768

### ► Solar Power Generation and Battery Charging:

1. Users must manually start the diesel generator to enable battery charging and power supply to the load.


2. Suppose Jason's **6.5kW** diesel generator has a nominal power of 6kW. It provides a stable three-phase output of **6kW** at **380V** and a single-phase output of **3kW** at **220V**. The recommended maximum operation time is 7 hours, and maximum cooling time is 1 hour.

Jason should manually start the generator to run for at least 60 minutes to charge the battery and maintain system operation during periods of low load and insufficient solar energy.


**Total Battery Energy:  $300\text{Ah} \times 51.2\text{V} = 15,360\text{Wh} \approx 15.36\text{kWh}$ .**  
**Battery SOC:  $3.25\text{kWh} \div 15.36\text{kWh} \approx 20\%$ .**

This operation charges about 20% of the battery, enough to sustain the system until solar generation resumes. Using our hybrid inverter, Jason can prioritize solar power as the primary energy source, with the diesel generator as a backup. By configuring the system correctly, the generator operates only when needed, reducing diesel use.

### Operating Guide:



1. Navigate to "Work Modes" and select "GEN".



2.This is our recommendation based on Jason's scenario.



3.This is our recommendation based on Jason's scenario.

# 13. Troubleshooting

Error Code	Description	Solutions
E10	Power module fault	<ol style="list-style-type: none"> <li>1. Check whether the power supply is normal.</li> <li>2. Replace the power-supply board.</li> </ol>
E13	Operating mode switched	<ol style="list-style-type: none"> <li>1. Reboot the inverter.</li> <li>2. Verify the operating mode in Settings.</li> </ol>
E14	DC current overload	<ol style="list-style-type: none"> <li>1. Reduce the load.</li> <li>2. Replace the control board.</li> <li>3. If the fault reappears, remove the main-board and test the IGBTs for short circuits.</li> </ol>
E15	Short-circuit protection	<ol style="list-style-type: none"> <li>1. Reboot the inverter.</li> <li>2. Replace the control board.</li> <li>3. Check whether the main-board IGBTs are shorted.</li> <li>4. Test whether the AC current transformer (CT) and its supply voltage are normal.</li> </ol>
E16	AC hardware overcurrent	<ol style="list-style-type: none"> <li>1. Replace the control board.</li> <li>2. Check the main-board IGBTs for faults.</li> <li>3. Test whether the AC CT is normal.</li> </ol>
E19	Hardware integration fault	<ol style="list-style-type: none"> <li>1. Reboot the inverter.</li> <li>2. Replace the control board.</li> </ol>
E21	PV or DC-DC hardware overcurrent	<ol style="list-style-type: none"> <li>1. Replace the control board.</li> <li>2. Inspect the main-board: check H6-bridge IGBTs and MOSFETs for shorts.</li> </ol>
E25	Low DC bus voltage during battery activation	<ol style="list-style-type: none"> <li>1. Verify the battery is operating normally; measure battery voltage.</li> <li>2. Check that the battery cables are properly connected.</li> </ol>
E29	CAN bus communication failure	<ol style="list-style-type: none"> <li>1. Ensure the communication cable is fully seated and connected to the correct port.</li> <li>2. Verify master/slave configuration between units.</li> <li>3. Replace the communication cable.</li> </ol>
E31	DC bus undervoltage in battery-less mode	<ol style="list-style-type: none"> <li>1. Check that AC input is present and its voltage is within the inverter's operating range.</li> <li>2. Confirm PV voltage is within range.</li> <li>3. If unresolved, replace the control board.</li> </ol>
E35	Overload protection	<ol style="list-style-type: none"> <li>1. Check whether output power is overloaded.</li> <li>2. Reduce load.</li> <li>3. If the fault occurs with no load, replace the control board.</li> </ol>
E37	DC-DC overcurrent (battery activation)	<ol style="list-style-type: none"> <li>1. Check if the battery entered protection; restart the battery.</li> <li>2. Reduce load.</li> <li>3. Replace the control board.</li> <li>4. If still unresolved, remove and test the main-board IGBTs and current transformers (CTs).</li> </ol>
E39	DC-DC overcurrent (software LLC)	<ol style="list-style-type: none"> <li>1. Check if the battery entered protection; restart the battery.</li> <li>2. Reduce load.</li> <li>3. Replace the control board.</li> <li>4. If still unresolved, remove and test the main-board IGBTs and current transformers (CTs).</li> </ol>

Error Code	Description	Solutions
E40	DC-DC current too high	<ol style="list-style-type: none"> <li>1. Check if the battery entered protection; restart the battery.</li> <li>2. Reduce load.</li> <li>3. Replace the control board.</li> <li>4. If still unresolved, remove and test the main-board IGBTs and current transformers (CTs).</li> </ol>
E41	Parallel-operation fault	<ol style="list-style-type: none"> <li>1. In a parallel system, ensure none of the inverters are off.</li> <li>2. Confirm all units are powered on.</li> <li>3. Check the parallel communication cabling.</li> </ol>
E45	AC voltage fault	<ol style="list-style-type: none"> <li>1. Reboot the inverter.</li> <li>2. Verify grid voltage is within the operating range.</li> </ol>
E46	AC voltage fault (grid undervoltage)	<ol style="list-style-type: none"> <li>1. Reboot the inverter.</li> <li>2. Verify grid voltage is within the operating range.</li> </ol>
E47	Grid frequency too high	<ol style="list-style-type: none"> <li>1. Reboot the inverter.</li> <li>2. Verify grid frequency is within the operating range.</li> </ol>
E48	Grid frequency too low	<ol style="list-style-type: none"> <li>1. Reboot the inverter.</li> <li>2. Verify grid frequency is within the operating range.</li> </ol>
E55	Parallel-operation fault	<ol style="list-style-type: none"> <li>1. In a parallel system, ensure none of the inverters are off.</li> <li>2. Confirm all units are powered on.</li> <li>3. Check the communication cabling.</li> </ol>
E60	Over-temperature protection	<ol style="list-style-type: none"> <li>1. Compare displayed temperature with actual.</li> <li>2. Check whether the fans are running.</li> <li>3. Ensure the air vents are unobstructed.</li> <li>4. Clean dust buildup at the vents.</li> </ol>
E61	Over voltage protection	<ol style="list-style-type: none"> <li>1. Check that battery voltage is within the operating range.</li> <li>2. If measured (telemetry) voltage is much higher than actual, replace the control board.</li> <li>3. If the issue persists, check the main-board battery voltage sampling circuit (component U44).</li> </ol>
E62	Under voltage protection	<ol style="list-style-type: none"> <li>1. Check that battery voltage is within the rated range.</li> <li>2. If measured (telemetry) voltage is much higher than actual, replace the control board.</li> <li>3. If still unresolved, check the main-board battery voltage sampling circuit (component U44).</li> <li>4. Verify the battery provides power.</li> <li>5. Check battery connections and that reported voltage matches actual.</li> </ol>

# 14. Technical Parameters

Technical Parameter		SUNT-6.0kW-S
<b>Battery Input (DC Input)</b>		
Supported Battery Type	LiFePO4 or Lead-Acid	
Battery Input Voltage Range (V)	40~60	
Max. Charge Voltage (V)	60 (Configurable)	
Max. Charge Current (A)	120 (Configurable)	
Max. Discharge Current (A)	130 (Configurable)	
Battery Capacity (Ah) (Recommend)	100~2000	
Charge for LiFePO4 Battery Pack	Communicating with BMS of the Battery Pack	
<b>PV String Input (DC Input)</b>		
Max. DC Input Power (W)	9600	
Max. DC Input Voltage (V)	500	
MPPT Voltage Range (V)	120~450	
Start-Up Voltage (V)	150	
Max. Input Current (A)	18x2 =36 2 MPPT Channels	
<b>AC Output (Back-Up) Feed to Essential Load</b>		
Max. Output Power (W)	6000	
Max. Output Apparent Power (VA)	6000	
Peak Output Apparent Power (VA)	12000	
Max. Output Current (A)	27	
Nominal Output Voltage (Vac)	220/230/240 (Configurable) Single Phase	
Nominal Output Frequency (Hz)	50/60 (+/-0.2%) (Configurable)	
Max. Bypass Current (A)	40	
Shift Time (Bypass and Inverter) (ms)	10	
Output THD (Resistor Load)	<3%	
<b>AC Input (On-Grid) Bypass to Essential Load/Charge the Battery/Feed to Home Load</b>		
Max. Input Power (W)	6000	
Bypass to Essential Load/Charge the Battery	6000	
Max. Output Power (W)	6000	
Feed to Home Load	6000	
Max. Apparent Input Power (VA)	6000	
Bypass to Essential Load/Charge the Battery	6000	
Max. Apparent Output Power (VA)	6000	
Feed to Home Load	6000	
Nominal Input/Output Voltage (V)	220/230/240 (Auto Adjusted to Fit Home Grid) Single Phase	
Nominal Input/Output Frequency (Hz)	50/60 (Auto Adjusted to Fit Home Grid)	
Max. Bypass Current (A)	40	
Shift Time (Bypass and Inverter) (ms)	10	
<b>Efficiency</b>		
Max. Efficiency	97.60%	
Max. Battery to Load Efficiency	94.0%	
Europe Efficiency	97.60%	
MPPT Efficiency	99.9%	
<b>Protection</b>		
Integrated	Battery Over Charge Protection, Battery Low Voltage Protection, Over Temperature Protection , Output Overload Protection, Output Short Circuit Protection, Output Over Voltage Protection	
<b>Certifications &amp; Standards</b>		
Grid Regulation & Safety/EMC Regulation	VDE-AR-N 4105; UNE 217001; G100; EN 50549-1; IEC 61727; IEC 62116; IEC 61683; IEC/EN 61000-6-1/3; IEC/EN 62109-1/2	
<b>General Data</b>		
Operating Temperature Range	-25°C~60°C (>35°C Derating)	
Protection Degree	IP65	
Size (LxWxH) (mm)	402x227x538	
Net Weight (kg)	26	



**Web:** <http://www.lumentree.co>    **Email:** [mcrey@lumentree.co](mailto:mcrey@lumentree.co)  
**Add:** 508B-2, Building 2, No.7 Beisha East Road, Donghu Street  
Linping District, Hangzhou, Zhejiang, China



Website



LightEarth

